



No.	Name	Note	No.	Name	Note
1	Angle valve	1/4"Flare	13	Angle valve	1/4"Flare
2	Discharge flange	4"	14	Refrigerant service valve	1/4"Flare
3	Solenoid valve	50%(NC)	15	Connector	1/4"Flare
4	Solenoid valve	75%(NC)	16	Liquid injection connector	5/8"Flare
5	Solenoid valve	25%(NC)	17	Suction flange	5"
6	Liquid(oil or refrigerant) injection connector	3/8"Flare	18	Cable box	Large
7	Capillary		19	Service flange	
8	Check valve	4"	20	Oil drain valve	option
9	Oil flow sight glass		21	Discharge temp. sensor	110°C
10	Service flange		22	Safety Valve	option
11	Stop pin		23	Economizer port	1 1/8", solder
12	Oil inlet connector	3/4"Flare	24	Solenoid valve	Stepless(NO), option

*All stop valves are optional.

RC19F PARTICULAR
Compressor Outline

