



No.	Name	Note	No.	Name	Note
1	Angle valve	1/4"Flare	11	Refrigerant service valve	1/4"Flare
2	Discharge flange	1 1/2"	12	Liquid injection connector	3/8"Flare, option
3	Solenoid valve	33%(NC)	13	Suction flange	2"
4	Solenoid valve	66%(NC)	14	Cable box	Standard
5	Liquid(oil or refrigerant) injection connector	1/4"Flare, option	15	Service flange	
6	Capillary		16	Oil drain valve	option
7	Check valve	1 1/2"	17	Discharge temp. sensor	110°C
8	Service flange		18	Economizer connector	3/8", solder
9	Oil Inlet Connector	3/8"Flare	19	Safety Valve	option
10	Angle valve	1/4"Flare	20	Solenoid valve	Stepless(NO), option

*All stop valves are optional.

Compressor Outline
RC10F, RC11F

